

F5.3 Temperature coefficient. This is the percentage that your battery’s capacity changes with temperature. The unit of this value is percent capacity per degree Celsius. The setting “OFF” disables temperature compensation.
Default: 0.50%cap/°C Range: OFF / 0.01 – 1.00 Step size: 0.01%cap/°C

F5.4 Peukert's exponent. The Peukert’s exponent represents the effect of reducing battery capacity at higher discharge rates. When the Peukert value of your battery is unknown, it is recommended to keep this value at 1.25. A value of 1.00 disables the Peukert compensation and could be used for Lithium-based batteries.
Default: 1.25 Range: 1.00 – 1.50 Step size: 0.01

F5.5 Self-discharge rate. This is the rate at which the battery loses capacity by itself, even when it is not used. The unit of this value is percent capacity per month at the Nominal temperature (F5.2). The setting “OFF” disables self-discharge compensation and could be used for Lithium based batteries.
Default: 3.0%/month Range: OFF / 0.1 – 25.0%/month Step size: 0.1%/month

F5.6 Charge Efficiency Factor (CEF). CEF is the ratio between the energy removed from a battery during discharge and the energy used during charging to restore the original capacity. It is recommended to keep this value at “AU” (automatic calculation). The setting “100” disables charge efficiency compensation.
Default: AU Range: 50 – 100% / AU Step size: 1%

F6: Battery Monitor Properties

F6.0 Firmware version. Displays the firmware version of the battery monitor (read only).
Default: x.xx

F6.1 Shunt Amp Rating. This Function is linked to F6.2 and represents the Amp rating of your shunt at the given voltage indicated by F6.2. Included with your battery monitor is a 500Amp/50mV shunt, meaning that at 500A flowing through the shunt, a voltage of 50mV is generated across the small ‘Kelvin’ screw terminals of the shunt. This voltage will be used by the battery monitor to measure the amount of current.
Default: 500A Range: 10 – 9000A Step size: variable

F6.2 Shunt milliVolt Rating. This Function represents the milliVolt rating of your shunt at the given current indicated by F6.1. The battery monitor supports 50mV and 60mV shunts.
Default: 50mV Range: 50/60mV

F6.3 Backlight mode. Represents the duration of backlight activation in seconds after key-press. The backlight can also be set to be always “ON” or always “OFF”. Function setting “AU”, activates the backlight automatically when charge / discharge current exceeds 1Amp or when a key is pressed.
Default: 30sec Range: OFF / 5 – 300 / ON / AU Step size: variable

F6.4 Alarm contact polarity. Enables selection between a normally open (NO) or normally closed (NC) contact.
Default: NO Range: NO/NC

F6.5 Voltage prescaler. This Function is only important when an optional voltage prescaler is installed on the battery monitor. All voltage related Functions are linked to this Function F6.5. Always keep this Function set to “1-1” when no prescaler is installed!
Default: 1–1 Range: 1-1 / 1-5 / 1-10

F6.6 Temperature unit selection. Enables selection between degrees Celsius (°C) and degrees Fahrenheit (°F) in the temperature readout.
Default: °C Range: °C/°F


F6.7 Auxiliary input mode. This Function is used to configure the VA input terminal on the rear side of the battery monitor, and can be set in two modes. In mode “0”, the VA input operates in normal voltage measurement mode. In mode “1”, the VA input can be used to control the backlight. In this mode, the backlight is switched ON at an input voltage higher than 2V and switched OFF again if the voltage is below 1V.
Default: 0 Range: 0/1

F6.8 Communication mode. This Function is used to configure the data output mode. There are four data output modes:
Mode “0”: LinkPRO (broadcasting)
Mode “1”: LinkPRO (request mode)
Mode “2”: XBM compatibility mode (broadcasting)
Mode “3”: XBM compatibility mode (request only)
Default: 0 Range: 0/1/2/3

F6.9 Setup lock. When set to “ON”, all functions (except this one) are locked and cannot be altered. The Reset menu is also locked.
Default: OFF Range: OFF/ON

Reset menu

In the Reset menu, you can reset a number of items of your battery monitor This menu can be accessed by the following sequence:



When the Reset menu is entered, you can use the < and > keys to browse through the different reset items. By pressing the MENU key, the selected reset item can be viewed. The default value for all reset items is “OFF”. To actually reset the selected item, use the < and > keys to change the value from “OFF” to “ON”. Pressing the MENU key again, will step back to the Reset menu. All reset items set to “ON” will only be reset once the Normal Operating Mode is accessed again by pressing the MENU key for 3 seconds. The following Reset menu items are available:

rSt.a	Reset alarms. Use this reset item to reset or ignore all current alarms.
rSt.b	Reset Battery status. Use this reset item to reset your current battery status (CEF, State-of-charge and battery history). You can use this reset item after you have installed a fresh battery of the same specifications as the previous one.
rSt.F	Reset Functions. This reset item can be used to reset all Function values to factory default values.
rSt.c	Reset zero-offset current. Use this reset item to remove small current readings on the display when no current is flowing in- or out of the battery. When performing this reset action, please be 100% sure that all DC consumers/chargers are disconnected or turned off.

Troubleshooting guideline

Problem	Remedy or suggestion
The monitor doesn't operate (no display)	<ul style="list-style-type: none"> • Check monitor and battery side connections. • Make sure the inline fuses are installed and not blown. • Check battery voltage. Battery might be flat. Vbatt must be >8VDC. • Try to restart the monitor by removing / placing the fuses again.
Current readout gives wrong polarity (positive current instead of negative when discharging)	<ul style="list-style-type: none"> • Current sense leads from the shunt are reversed. Check the installation guide.
The monitor resets all the time	<ul style="list-style-type: none"> • Check the wiring for corrosion and / or loose contacts. • Battery might be flat or defective.
No changes can be made in the Function setup	<ul style="list-style-type: none"> • Check if the setup-lock is OFF (Function F6.9) • Your LinkPRO might be locked by the superlock. Ask the installer for the password to unlock the monitor using the LinkPRO Communication Kit.
“CHARGE” or “SYNCHRONIZE” keeps on flashing	<ul style="list-style-type: none"> • Charge battery full (synchronize your battery with the monitor) • Check the Auto-sync parameters in Functions F1.0, F1.1 and F1.2 for possible wrong settings.
State-of-charge and/or time-to-go readout not accurate	<ul style="list-style-type: none"> • Check if all current is flowing through the shunt (the negative terminal of the battery may only contain the wire going to the battery-side of the shunt!). • Current sense leads from the shunt are reversed. • Check all Battery properties Functions (F5) • Check if battery monitor is synchronized.
Display returns '- - -' in temperature readout	<ul style="list-style-type: none"> • Connection with temperature sensor is lost. Check for failed connections and/or cable damage.
Battery voltage readout is highly inaccurate	<ul style="list-style-type: none"> • Check prescaler setting in Function F6.5

Specifications

Parameter	LinkPRO
Supply voltage range	9 – 35VDC
Supply current ¹ @Vin=24VDC	7mA
@Vin=12VDC	9mA
Input voltage range (auxiliary battery)	2 – 35VDC
Input voltage range (main battery)	0 – 35VDC
Input current range ²	-9999 – +9999A
Battery capacity range	20 – 9990Ah
Operating temperature range	-20 – +50°C
Readout resolution:	
voltage (0 – 35V)	±0.1V
current (0 – 199A)	±0.1A
current (200 – 9999A)	±1A
amphours (0 – 199Ah)	±0.1Ah
amphours (200 – 9999Ah)	±1Ah
state-of-charge (0 – 100%)	±0.1%
time-to-go (0 – 100hrs)	±1 minute
time-to-go (100 – 240hrs)	±1 hr
temperature (-20 – 50°C) ³	±0.5°C
Voltage measurement accuracy	±0.3%
Current measurement accuracy	±0.4%
Dimensions:	
frontpanel	ø 64mm (2.54")
body diameter	ø 52mm (2.05")
total depth	ø 79mm (3.11")
weight	95grams (0.21 lbs")
Shunt dimensions:	
footprint	45 x 87mm (1.77"x3.43")
(M8 screws) height	17mm (0.67") (base) / 35mm (1.38")
weight	145grams (0.32lbs)
Protection class	IP20 (frontpanel only IP 65)
LinkPRO Accessory Connection kit	854-2021-01 (15m, 50ft)
LinkPRO Accessory Communication kit	854-2019-01
LinkPRO Accessory Temperature sensor kit	854-2022-01 (10m, 32ft)

1. Measured with backlight and alarm relay turned off
2. Depends on selected shunt. With standard delivered 500A/50mV shunt (350A continuous), the range is limited to -600 – +600A.
3. Only available when optional temperature sensor is connected.

